

360 MOUNT FOR TERROVA

The 360 for Terrova has a Motor Housing, Clamp, Shaft Clamp, Tube and 3 Split Rings.

Attach the Motor Housing Clamp to the Motor Housing with the socket head screws. Tighten the set screws at the Housing Base. **DO NOT OVER TIGHTEN!** Attach the Shaft Clamp to shaft with the plastic inserts going around the Terrova shaft. Leave a little loose for now. Attach the 2 split rings on either side of Shaft Clamp and tighten. Slide the wire through tube and onto the 360 shaft with the split in the tube at the bottom. Clamp the split tube with split ring. Slide the tube through the Motor Housing Clamp and through the top Shaft Clamp. Tighten the Shaft Clamp. Adjust your 360 Shaft Length by moving the 2 split rings up or down the trolling motor shaft. Get the length set and tighten the split rings against the collar of the Shaft Clamp.

