

Read PRIOR To Installation!

Garmin Panoptix / Live Scope Installation Instructions

- Installation is best done with Trolling motor in the stowed position.
- Top bracket is installed directly under Trolling Motor head.
- Insert tube into bottom bracket and tighten socket head cap screw
- Heat hose at 220°F for 15 minutes. Insert cable in coiled hose. Hose is split down the middle; a screwdriver will help.
- Loosen hose clamp located on top of tube and insert hose and cable and tighten.
- Install Garmin Transducer on tube a **minimum of 7 inches** from Trolling Motor Housing.
- Coiled hose should be taut but loose enough to turn 360 degrees without binding.
- **DO NOT** over tighten brackets. Doing so will cause the center portion of the bracket to bottom out and bracket will not fit properly. Brackets should fit snug and having a gap at the marriage line on both ends is normal.

